

SilentStream[®] Upgraded Version : With Easy-Fill Reservoir Tube.


Dear Customer :

Thank you for buying *SilentStream*[®] , as you have already discovered you do not have the unit that is featured on the front of the box or in the manual. Don't worry! What we have supplied you is the upgraded version.

Please note below the benefits of this upgrade (all other specifications remain the same) :



SilentStream[®] Original: Hard tube with LED indicator




SilentStream[®] Upgraded : Long size soft tube

Advantages of *SilentStream*[®] upgraded version :


1. Compatible with ATX cases that have limited inner space
2. Refill the water reservoir without laying the case on it's side
3. Water volume in reservoir is increased.
4. The water level can be verified from outside the case (if the case is equipped with a clear side panel window)
5. The water reservoir refill frequency is decreased from once every three weeks to once every three months. (The real duration depends on the CPU category : lower CPU clock , lower refill frequency)

Installation of *SilentStream*[®] Upgraded Version:

1. Stick plastic buckle on the side panel of PSU
2. Push down the cap after finishing water replenishment to *SilentStream*[®] Upgraded version , fix the long soft tube into the buckle .



Buckle



Finish look of *SilentStream*[®] Upgraded version **in Pro Installation**
(Radiator is placed outside the case, Best Heat Dissipation)

Finish look of *SilentStream*[®] Upgraded version **in Quick Installation**
(Radiator is placed inside the case, Rapid Installation)

3. Please refer to the printed or CD-Rom manual of *SilentStream*[®] Original version for other installation details .